# CATERPOLLAR
QUICK START GUIDE

SPECIFICATION

- **Dimension:** 31.5 mm x 18.5 mm x 70 mm
- **Net Weight:** 30g
- **Light Bead:** Super bright COB LED
- **Material:** Engineering plastic , rubber.
- **Packaging includes:**Caterpollar bike Light×1 Light base×1 Rubber strap×1

CHARGING

- **In use:** Red light is always on.It starts flashes when battery reaches 10%.
- **Charging:** Red light flashes during charging, it becomes lingt-on when it is charged to 100%.

MOUNTING

- Installed on bicycle seat post. (3-1)
- Clipped on clothes during night running. (3-2) (3-3)

(3-1)   (3-2)   (3-3)

REFERENCE DATA

Mode	Time
High bright	02:40
Low bright	04:10
High Flashing	10:15
Low Flashing	30:30
Pulse	10:30
Ecology	06:40
SOS	11:30
Charging	01:30

DANGER!

- Polymer battery inside. Please do not heat or burn the light to avoid explosion. Please charge the bike light with a qualified USB charging power adapter. Using defective USB charging ports may cause electric shock, fire disaster,etc. VOLO is not responsible for any of such consequences.

LUGHT ON/OFF

- **Light On:** Long press the button for 1.5 seconds to turn on the light.
- **Light Off:** Long press the button for 1.5 seconds to turn off the light.
 (It is recommended to fully charge battery when using it for the first time)

(1-1)

CHARGING MRTHOD

- Computer USB port. (2-1)
- Socket with USB Port. (2-2)

USB2.0

(2-1)   (2-2)

MULTIPLE APPLICATION

(4-1)Cycling   (4-2)Running

(4-3)Climbing   (2-3)Skateboarding

ATTENTION

- Make sure bike light is mounted securely before each ride for your safety.
- Check the battery and charge it full before your first riding.
- Avoid using it in high or low temperature environments to maintain best battery performance and LED battery life display accuracy.
- Charge your light every 3 months for long term storage.
- Please make two complete charging and discharging cycles to calibrate the led display after long term storage.